

# ProfCam *by Ken-A-Vision*<sup>®</sup>

## CeilingDocCam II 910-171-066



A ceiling-mounted camera that captures detailed images for display on a variety of devices. The CeilingDocCam II delivers superb image clarity for monitors, plasma screens, video projectors and videoconferencing systems. A wide field of view and six zoom settings make it easy to use with different document sizes - from large documents such as blueprints or CAD drawings to an area the size of a postage stamp.

### CEILING DOCCAM II ADVANTAGES

#### Superior Image Quality and Performance

- Wide field of view captures large documents
- Up to 300X zoom provides excellent detail
- Works with monitors, plasma screens, video projectors and videoconferencing systems
- High-quality CCD image sensor delivers 480 TV lines of full-motion video for superb image clarity and color
- Outputs both composite and S-Video signals concurrently for dual-monitor display in large rooms

#### Easy to Use

- Single Cat.5 cable carries video control and power signals
- Laser positioning guide makes document placement simple
- Six preset zoom settings makes it easy to adjust for different document sizes
- RS-232 port with VISCA<sup>™</sup> control protocol cables easy connections to a control system

#### 910-171-066 SPECIFICATIONS

Weight	4 lbs / 1.81 kg	White Balance	Auto
Enclosure Size	4.5" X 6.5"	Brightness	Auto/Manual
	11.43 cm X 16.51 cm	Backlight Compensation	Auto
Ceiling Cutout	3.5" (8.9 cm) Diameter	Iris	Auto
Enclosure	Plenum-rated	Image Type	Super HAD CCD
Wall Plate	S-Video, Composite, Power & RS-232	Resolution	480 Lines
Focus	Auto/Manual	Output Signal	Composite
Zoom	Optical 25x, Digital 12x (300x total with optical zoom)	Warranty	S-Video
Illumination	2.5 Lux		3 Years

Specifications subject to change without notice



**ken-a-vision**<sup>®</sup>  
KNOWLEDGE THROUGH VISION

(816) 353-4787 Fax (816) 358-5072

email: [info@ken-a-vision.com](mailto:info@ken-a-vision.com)

kav.fly.910171066.107v3